

## Vanity Top - Installation Instructions

Be sure to completely read this installation guide before removing vanity top from box and installing.

**CAUTION:** This vanity top is heavy. We recommend two people for lifting and installing. Remember to bend at the knees, not at the waist when lifting heavy objects!

This box contains the following:

- 1 (one) Natural stone vanity top with attached porcelain bowl
- 1 (one) 4" loose backsplash
- 1 (one) Installation/Care & Maintenance/Warranty Brochure

Your granite, marble or travertine vanity top is made of natural stone quarried from the earth. Every slab of natural stone has its own unique characteristics, such as veining and coloration. Be sure to fully inspect your top for satisfaction before installation.

Tools Needed:

- 1. Caulking gun
- 2. Silicone sealer
- 3. Caulking adhesive

(It is our experience that GE Silicone is not the best match with our natural stone products and should be avoided.)

1. Prepare and level the vanity cabinet and secure it to the wall. Use additional interior supports if the vanity is frameless or does not have full support around the frame. Your granite, marble or travertine vanity top is heavy natural stone. Additional wood supports should be 1" x 2" and affixed to the sides with caulking adhesive and short wood screws that do not protrude through any exposed sides. Be sure to follow the recommended instructions for installation from your vanity cabinet manufacturer.

Helpful Hint #1: Be sure to hand tighten wing nuts on the bottom of your natural stone vanity top, that may have loosened during shipping, before attaching to vanity cabinet.

2. Apply a bead of silicone sealer on the top edges of the vanity cabinet. Place your natural stone top on it with an overhang of 1/2" on the edges and permit the sealer to dry. See manufacturer's instructions for drying time.

