

CABOT FRENCH PATTERN SPACING AND GROUT

Grout line thickness adjustment has to be done from the start of installation to avoid progression of the thickness. It is recommended to make a dry run of the pattern kit prior to setting to avoid such issues:

Installed Photos with Spacing and Grout:

