

WPC CLICK LOCK INSTALLATION INSTRUCTIONS

Safety First

Be good to yourself; make sure you use proper lifting techniques when you handle these products. Use proper protection when using a knife.

Material Storage and Conditioning

All flooring material must be stored in a protected environment. The material should be conditioned in a job site at a temperature of 60°F to 95 °F for 48 hours before installation. Without proper conditioning, it may cause difficulties during installation.

Job Site Preparation

The job site should be conditioned for 48 hours between 60°F and 95°F. The subfloor needs to be cleaned, reasonably smooth and flat. All depressions should be filled. High point and bumps must be removed by sanding. The concrete subfloor must be dry. Trowel lines must be sanded out.

INSTALLATION

This floor must be installed with glueless installation only.

1. Plan first; avoid having very short pieces and/or very narrow pieces.
2. It is generally recommended that you install the long side of the plank parallel to the long side of the work area.
3. Maintain a random appearance and offset the end line for a better look.
4. First install the first row along the wall. Leave about 1/8" space to the wall. Hold the new board at an angle of 15 to 20o to the previously installed board, and lineup the lip at the butt end of the boards. Make sure the first row is very well aligned.
5. To start the 2nd row, cut a plank to a length, so the position of the end line of the second plank is at least 6" from the end line of the first plank. The end lines should NOT be lined up
6. Lineup the lip at the short side of the butt end of the boards. Lift the new board and connecting board at an angle of 15 to 20 degree (that is just enough to put the figures beneath the board, don't lift too high). Engage the long side of tongue and groove and push the new board gently up. When the long side tongue and groove are fully engage, put down the boards.



7. It is critical you install the first two rows straight and square. It is the base for the whole installation.
8. Repeat the step 5 and 6 to complete the installation.
9. The maximum area of installation for Luxury Vinyl Plank/Tile without transition strips is 25ft Wide X 30ft Long. Once these dimensions have been exceeded appropriate transition strips will need to be used.

Tip 1: When cut the boards, you can just cut through the surface then bend the board, the board will break clean.

Tip 2: If a small part of tongue and groove or corner is damaged, just remove the damaged part and installed the floor as usually. This will not affect the installation strength.

Finish Installation

1. Do NOT wash the floor immediately after installation. Use a damp mop to clean the floor.
2. Keep the room temperature in between 60oF to 95oF for 48 hours.