



## Installation Instructions:

Hewn reproduction reclaimed barn wood is a natural wood product designed to match the patina and texture of reclaimed barn wood. Please consult a professional contractor with specialty installations.

### Standard Installation.

1. Measure the area you intend to cover, height x width = square footage. Once you determined your square footage make sure you order an additional 10% for cut offs.
2. After opening and inspecting the barn wood, begin by measuring and cutting the appropriate sizes.
3. Either face nail or screw directly through the lumber or apply wood glue adhesive and nail with a pin nail gun.
4. Apply touch paint where needed. Touch-up for cuts and raw wood, for grey tone colors use Valspar Portland Twilight (VR108B) Exterior flat water based paint and blend with water at a high ratio of 4 parts waters to 1 part paint. For brown tones use Valspar Black Hills Shadow (VR094A) Exterior flat, water based paint and blend with water at a ratio of 3 parts water to 1 parts paint. Brush solution on raw wood and let dry. Be sure to use a brush small enough to coat the area needed without overlapping onto the already colored wood and let dry. It is alright to adjust the dilution or apply multiple coats if desired. This solution will act as a stain and should only be used for touch-up.