Recommended Tools for Assemble Cabinets

Screw Driver

Senco Fastener

Nail Gun

Stapler

Rubber Hammer

Clamp

Glue Gun or Wood Glue

Spare Screws

Instruction For the Following Styles:

Cherry Glazed Maple
Honey Maple
French Antique Glazed Maple
Vanilla Glazed Maple

Chocolate Glazed Maple
Mocha Glazed Maple

1. Remove the door panel from frame. It is best to re-install the door after the installation of all cabinets.

2. Place the side panel to the groove of the frame.

3. Secure the side panel to the frame using 1/4" wide by 3/4" deep staples every 6".

4. If you are using hot glue or wood glue, make sure to apply a thin layer of glue over the connection of the side panel and the frame.

5. Repeat Steps 3 and 4 with the other side panel.

6. Silde the bottom panel through the grooves and staple every 4-6" and apply hot glue or wood glue.

7. Slide in the back panel starting from the bottom sliding towards the top.

8. Make sure both panels are aligned. Otherwise, it will be very difficult to level the plywood for the countertop.

9. Staple the bottom of the back panel to secure it to the outter frame (use 3/4" staples every 4-6")

10. Staple the side panels to the cabinet for extra reinforcement. Use either 3/4" or 1" staples.Use two staples on each side of the cabinet.

11.Locate the toe kick.

12. Staple the toe kick to the bottom of the cabinet using 3/4" staples every 4-6".

13. The cabinet is now ready for installation..

Instruction For the Following Styles:

Cherry Glazed Maple
Honey Maple
French Antique Glazed Maple
Vanilla Glazed Maple

Chocolate Glazed Maple
Mocha Glazed Maple

1. Locate all of the following parts:
   a. Bottom panel
   b. Two side panels (long ones)
   c. Back panel
   d. Front panel (drawer face)

2. Connect the side panel to front panel. Optional: Use carpenters glue to glue the dove tails.

3. Connect the second panel.

4. Slide in the bottom panel to the groove on the bottom.

5. Join the back panel. Make sure that the notch and the pre-drilled holes are facing down.

6. Locate the pre-drilled holes on the side of the cabinet. Connect the drawer guides using a screwdriver.

7. Make sure the front of the drawer guides align with the back side of the face frame. In the photo the left guide is installed correctly. The right one is NOT CORRECT because the front of the guide passes the back side of the face frame.

8. Slide drawer until the pins are in the holes.

9. Insert the pins in the holes.
   Note: The round plate under the pin can be used for easy adjustments.

   Great! Your drawer is done.