



MAINTENANCE AND CLEANING

LAMINATE FLOORS is a hygienic, easy-care floor, quickly cleaned with a soft brush or vacuum cleaner. Wipe footprints and clinging dirt along the length of the planks with a slightly moist cloth. Surplus moisture should be removed immediately. Remove heavy soiling and stubborn marks with small amounts of specially designed and commercially available brand of laminate flooring cleaner. Never use any other cleaning agents containing wax, oil, polish or scouring agents as they may dull or distort the finish. The manufacturer cannot be held responsible for damage to the floor from the use of inappropriate or excessive amounts of cleaning agents or water.

In especially dirty areas, mats should be laid on the laminate in order to create clean walk zones. To maintain the quality of your laminate floor, use rubber or felt protectors under the legs of your furniture and soft rubber castors complying with the wheel bearing surfaces standard DIN 68131 types "W".

A healthy room climate with room temperature of 64°F - 73°F (18°C - 23°C) and relative humidity of 55-65% is as important for your laminate floor as it is for you and your family. Humidity should never be allowed to drop below 30% as this may cause gapping. You can repair slight damage to the planks yourself with laminate flooring repair products such as, Color-Fill. In the case of more serious damage, you should consult a specialist.

To avoid scratches apply felt pads to your furniture legs and use only soft rubber casters. Protect high traffic areas with runners and area rugs.

It is a good idea to save a few boards in case of accidental damage. Boards can be replaced or repaired by a flooring professional.