


# Technical Information — Sizes

## Stair Nose

The Landing Stair Nose combines style and function to enhance the beauty of a staircase or step

**Surface Material:** High Wear Resistant Aluminum Oxide Laminate


**Core Material:** Moisture Resistant MDF



## Versatrim Shim


Use one to raise the Stair Nose when used for a 12 mm floors and two for 15 mm Floors

**Material:** Standard HDF




# Installation

## 7 – 9 mm Floors



## 12 mm Floors


Use Versatrim Shim for 12 mm floors.



Stair Nose


Installation WITHOUT using Shim for floors from 7 - 9 mm in thickness.

**7 - 9 mm Floors**




**Step 1**

Install the riser flush to the Stair. Leave 1-5/8" (41mm) distance between the outer edge of the riser and the laminate floor. Put down two lines of construction adhesive.



**Step 2**

Predrill and countersink the stair nose in a distance of approximately 10".





**Step 3**

Firmly screw the molding to the stair. Finish up the #6 x 1-1/4" screws with a color matching Color Fill.


Installation using Shim for floors 12 mm in thickness.

**12 mm Floors**




**Step 1**

Install the riser flush to the Stair! Leave 1-5/8" (41mm) distance between the outer edge of the riser and the laminate floor. Put down two lines of construction adhesive.



**Step 2**

Place the Shim on the bottom of the molding and predrill and countersink the stair nose in a distance of approximately 10".



**Step 3**

Firmly screw the molding to the stair. Finish up the #6 x 1-1/4" screws with a color matching Color Fill.